

# **DBW-4**

Drive By Wire Controller

## **User Manual**

© Copyright – MoTeC Pty Ltd – 2001-2006

The information in this document is subject to change without notice.

While every effort is taken to ensure correctness, no responsibility will be taken for the consequences of any inaccuracies or omissions in this manual.

7 February, 2006

## Contents

---

<b>Introduction .....</b>	<b>3</b>
<b>Abbreviations &amp; Definitions .....</b>	<b>4</b>
<b>Inputs &amp; Outputs .....</b>	<b>5</b>
<b>PID Fault Conditions.....</b>	<b>6</b>
<b>Communications.....</b>	<b>7</b>
CAN.....	7
Firmware Upgrades.....	7
<b>Configuration .....</b>	<b>8</b>
Drive By Wire Calibration .....	9
Generic PID Controller Calibration .....	11
Diagnostic/Fault Condition Monitoring.....	13
Firmware Upgrades.....	13
<b>Appendices.....</b>	<b>14</b>
Appendix A: General Specifications .....	14
Appendix B: Input Characteristics .....	15
Appendix C: Output Characteristics .....	16
Appendix D: CAN Wiring – Multiple Device.....	17
Appendix E: DBW-4 to M800 Wiring .....	18
Appendix F: DBW-4 Pin List by Pin Number .....	19
Appendix G: DBW-4 Connector .....	20
<b>Notes .....</b>	<b>21</b>

## Introduction

This manual describes the functions and specifications of the MoTeC DBW4, and configuration for use with the MoTeC “hundred” series ECUs (M400, M600 & M800). The DBW-4 works with ECU Firmware V3.30T and later.

The DBW4 provides 4 PID Controllers for drive by wire control or generic PID control.

PID Set points are received from the ECU over the CAN bus and are separate for each PID Controller. Each controller can be individually configured for use as a generic PID Controller or drive by wire PID Controller.

When configured as a drive by wire PID Controller, the throttle position is tracked with 2 analog inputs for each throttle body. Error checking is done on these inputs to ensure safety. Drive by wire PID Controllers have some common functionality in that if one controller must be shutdown, for safety or due to an error condition, all other drive by wire PID Controllers will be shutdown automatically.

When configured as generic PID Controllers, only one analog input is used per PID Controller for feedback, leaving the remaining analog input for general use.

All scaled analog input values are transmitted over the CAN bus as well as PID fault conditions.

The **DBW-4** has the following inputs and outputs:

- 8 Analog voltage inputs (AV 1-8) for PID Controller feedback and generic use.
- 8 PWM outputs (4 pairs) for PID Controller output.

The DBW-4 uses a 66 pin Autosport connector.

## **WARNING!**

**Drive by wire throttle body motors are very powerful and can cause serious injury to users or damage to the throttle body. Never attempt to move the butterfly by hand with the motor connected to the DBW-4 Unit.**




Figure 1: DBW-4 Unit in a drive by wire application

## Abbreviations & Definitions

---

DBW	- Drive By Wire
ECU	- Engine Control Unit
O/P	- Output
PID	- Proportional, Integral, Derivative Controller
PWM	- Pulse Width Modulation
TP	- Throttle Position One
TP2	- Throttle Position Two
TPD1	- TP One Driver
TPD2	- TP Two Driver
UTC	- USB to CAN converter

### Measured Value 1 & Measured Value 2

For drive by wire PID applications Measured Value 1 refers to TP & Measured Value 2 refers to TP2.

For generic PID applications Measured Value 1 is the analog input used for PID Controller feedback. The second analog input is not used by the PID Controller and can be used as a generic analog input.

## Inputs & Outputs

---

### ***Inputs (AV1 – AV8)***

The DBW-4 has eight 0-5V analog voltage inputs (AV1 to AV8). These are suitable for Potentiometers, voltage output sensors and variable resistance (temperature) sensors (these require an external pull-up resistor to 5V).

These inputs are directly connected to the TP & TP2 position potentiometers on drive by wire throttle bodies.

### ***Outputs***

All outputs are disabled until the first CAN message is received. Outputs are disabled after no CAN messages have been received for one second, but will resume once communication is re-established.

When outputs are disabled, all power is removed, relying on a safe return mechanism to return the actuator to a safe position (eg. The butterfly valve return spring on a throttle bodies).

## PID Fault Conditions

---

This section describes the fault conditions for each type of PID Controller. These fault conditions will be monitored by the ECU for safe operation. During installation and fault finding, these conditions can be examined with the Motec DBW-4 Manager software.

### **Commanded Shutdown**

This is not strictly an error condition, but is included with the fault flags and hence handled here. A Commanded Shutdown occurs when the ECU sets the set point of a PID Controller to a value of 1024. All other drive by wire PID Controllers will shutdown. For Generic PID Controllers only the controller with a set point of 1024 will be shutdown. For safety reasons, a power cycle is required to return to normal operation.

### **No Config Error**

This condition occurs when the unit is powered, but not yet configured. In other words the range for both feedback inputs (analog inputs) of the PID Controller is zero (TP & TP2 for drive by wire PIDs) or when the range of the first feedback input of the PID Controller is zero (generic PIDs). Un-configured PID Controllers will be shutdown until configured.

### **Measured Value 1 & Measured Value 2 Tracking**

This error condition only applies to drive by wire PID Controllers. This error condition occurs when TP & TP2 values are not tracking to within 10% of each other for more than 2 seconds. Since safe operation can not be ensured under this condition, all drive by wire PID Controllers will be shutdown.

### **Set Point and Measured Value 1 Tracking**

This error applies to all PID Controller types. This error condition occurs when the feedback value for the PID and the required set point do not correlate to within 10% for more than 1 second. For a drive by wire application, if the throttle position differs by more than 10% from the required (specified) position for more than 1 second, the PID Controller (and all other drive by wire PID Controllers) will be shutdown.

### **Status/PWM Error**

This error applies to all PID Controller types. This error condition occurs when an over-current or over-temperature condition occurs. The limit for over-current is 8A and for over-temperature in the range 160°C to 190°C. This condition shuts down the PID Controller. If the PID Controller is a drive by wire type, all other drive by wire PID Controllers will be shutdown as well. For safety a power cycle is required to clear this error.

### **Measured Value 1 End Of Scale**

This error applies to all PID Controller types. This error condition occurs when Measured Value 1 (TP for drive by wire PID Controllers) goes more than a certain amount above or below the calibrated maximum or minimum values for a more than 1 second. This will cause the PID Controller to be shutdown and all PID Controllers to be shutdown if this controller is a drive by wire type.

### **Measured Value 2 End Of Scale**

This error only applies to drive by wire PID Controller types. This error condition occurs when Measured Value 2 (TP2 for drive by wire PID Controllers) goes more than a certain amount above or below the calibrated maximum or minimum values for a more than 1 second. This will cause the PID Controller to be shutdown (and all drive by wire PID Controllers to be shutdown if this controller is a drive by wire type.)

### **No CAN Communication**

This condition can not be monitored from the MoTeC DBW-4 Manager Software, but still causes the PID Controllers to shutdown, although only temporarily. If no CAN message is received for more than 1 second, all PID Controllers are shutdown. Once communication is re-established, operation will continue as before. No power cycle is required to clear this error.

## Communications

---

### CAN

---

The CAN bus is used for PC communications during testing, calibration and firmware upgrades, and for communicating to the ECU.

The following data is transmitted by the DBW-4 at 200Hz:

- Measured Values 1 & 2 for each PID (AV1-AV8)
- Measured Value 1 with PID diagnostic information.

The following data is transmitted by the DBW-4 at 50Hz:

- Output driver faults
- Internal temperature
- Internal voltages (-5v, 8vAux, 5vAux, Vbat, 4.5v)
- DBW-4 status flags
- DBW-4 firmware version

The following data is received by the DBW-4 from the ECU:

- PID1 to PID 4 set points

### Firmware Upgrades

---

At times MoTeC may release firmware upgrades for the DBW-4 Units. Upgrades are performed over the CAN bus using a MoTeC CAN cable and the MoTeC DBW-4 Manager Software. See the section DBW-4 Configuration for more information. Currently the MoTeC DBW-4 Manager Software does not support the MoTeC UTC.

# Configuration

The DBW-4 unit is configured using the MoTec DBW-4 Manager Software. This software can load/save configurations and display diagnostic information. DBW-4 Manager communicates with the DBW-4 using the MoTec CAN cable.

The software is used to configure all PID Parameters as well as calibrate the maximum, minimum and measured value ranges.


Before starting configuration and setup, ensure that all wiring to the actuators and sensors are complete as well as all power and communication wiring.

The main window of DBW-4 Manager is shown below, with the settings for each of the four PID controllers on a separate tab. Each PID controller can be disabled, or configured as either a Drive By Wire or generic ("Other") PID controller.

Values for PID parameters are specified in the documentation supplied by MoTec for each throttle body, and are the same parameters that the MoTec ECU Manager software uses for single drive by wire applications (ie. non DBW-4 applications)

Configuration files for several drive by wire motors are supplied with the DBW-4 Manager software. These files have all the PID Parameters for the motor type, but the motor must still be calibrated before it can be used.

A configurations (with a completed calibration) must be sent to the DBW-4 before it will take effect. The configuration is sent to the DBW-4 by selecting the Send Config menu option or by pressing F5.





## Drive By Wire Calibration

### WARNING!

Drive by wire throttle body motors are very powerful and can cause serious injury to users or damage to the throttle body. Never attempt to move the butterfly by hand with the motor connected to the DBW-4 Unit.

To calibrate a DBW throttle body, the high and low limit positions must be measured and included in the calibration. The procedure calibration procedure described here should be repeated for each DBW throttle body connected to the DBW-4.

#### Step 1:

Run the DBW-4 software and load the appropriate configuration file for the DBW motor, or enter the appropriate PID parameters. If one of the supplied configuration files is loaded, it is recommended that the configuration be saved under a new name before continuing with the calibration.

#### Step 2:


Connect the CAN cable from the PC to the DBW-4 and apply power to the DBW-4. Ensure that only the sensor wiring (TP, TP2, +5V and 0V) is connected to the DBW throttle body, and that the wiring to the motor is disconnected before applying power.

#### Step 3:

Click on the Tab (PID1 to PID4) for the DBW throttle to be calibrated. Ensure that the Group type for the controller is set to "Drive By Wire". Press the Calibrate button to begin the calibration. After reading the displayed safety warning and checking the motor wiring, click Next to continue.

#### Step 4:

Set the low limits for the measured position by following the instructions displayed (see below). For indication purposes, the raw position values for the two measured values will be displayed as the butterfly valve position is changed. Note that the Set button can be pressed again if the butterfly position was set incorrectly. When the low limit position has been set, click Next to continue.



The screenshot shows a software window titled "Calibrate" with a blue header bar and a close button in the top right corner. The main content area has a light beige background. It displays "Step 2" followed by instructions: "Using a feeler gauge of approximately 0.5 mm, press on the butterfly until it clamps the feeler gauge. Set the low limit position for Measured Value 1 (TP) and Measured Value 2 (TP2) by clicking the Set button." Below the text are two input fields: "Measured Value 1 (raw):" with the value "836" and "Measured Value 2 (raw):" with the value "221". A "Set" button is positioned to the right of the first input field. At the bottom of the window are three buttons: "< Back", "Next >", and "Cancel".

Step 5:

*This step is only applicable for DBW throttle bodies with a linear characteristic for the Meas2 (TP2) sensor (ie. Meas2 Max % Target = 100%), where the high limits for both measured values are set at the same time.*

Set the high limits for the measured values by following the instructions displayed (see below). For indication purposes, the raw position values for the two measured values will be displayed as the butterfly valve position is changed. Note that the Set button can be pressed again if the butterfly position was set incorrectly. When the high limit positions have been set, click Finished to continue.

Calibrate

Step 3

Move the butterfly to the full throttle position, ensuring that the butterfly is NOT opened past the full throttle position. The full throttle position must be set at least 2 degrees of rotation from the open throttle mechanical stop position. Set the high limit position for Measured Value 1 (TP) and Measured Value 2 (TP2) by clicking the Set button.

Measured Value 1 (raw): 835      Set

Measured Value 2 (raw): 221

< Back      Finished      Cancel

Step 6:

*This step is only applicable for DBW throttle bodies with a “knee” characteristic for the Meas2 (TP2) sensor (eg. Meas2 Max % Target = 62.5%), where the high limit is measured separately for measure value 1 (TP) and measured value 2 (TP2).*

Set the high limit for the measured value 1 (TP) by following the instructions displayed (see below). For indication purposes, the raw position values for measured value 1 will be displayed as the butterfly valve position is changed. Note that the Set button can be pressed again if the butterfly position was set incorrectly. When the measured value 1 high limit position has been set, click Next to continue.

Calibrate

Step 3

Move the butterfly to the full throttle position, ensuring that the butterfly is NOT opened past the full throttle position. The full throttle position must be set at least 2 degrees of rotation from the open throttle mechanical stop position. Set the high limit position for Measured Value 1 (TP) by clicking the Set button.


Measured Value 1 (raw): 835      Set

< Back      Next >      Cancel

Step 7:

This step is only applicable for DBW throttle bodies with a “knee” characteristic for the Meas2 (TP2) sensor (eg. Meas2 Max % Target = 62.5%), where the high limit is measured separately for measure value 1 (TP) and measured value 2 (TP2).

Set the high limit for the measured value 2 (TP2) by following the instructions displayed (see below). It is important to position the butterfly as close to the target (eg. 62.5%) as possible when setting measured value 2. Note that the Set button can be pressed again if the butterfly position was set incorrectly. When the measured value 2 high limit position has been set, click Finished to continue.



Step 8:

When all calibrations have been performed, send the configuration to the DBW-4 by pressing the F5 key.

## Generic PID Controller Calibration

---

To calibrate a generic PID controller, the high and low limit positions must be measured and included in the calibration. The procedure calibration procedure described here should be repeated for each PID controller connected to the DBW-4.

Step 1:

Run the DBW-4 software and load the appropriate configuration file for the connected device, or enter the appropriate PID parameters.

Step 2:


Connect the CAN cable from the PC to the DBW-4 and apply power to the DBW-4. Ensure that only the sensor wiring (TP, +5V and 0V) is connected to the device and that the wiring to the actuator is disconnected before applying power.

Step 3:


Click on the Tab (PID1 to PID4) for the controller to be calibrated. Ensure that the Group type for the controller is set to “Other”. Press the Calibrate button to begin the calibration. After reading the displayed safety warning and checking the actuator wiring, click Next to continue.

Step 4:

Set the low limit for the measured position by following the instructions displayed (see below). For indication purposes, the raw position value will be displayed as the actuator position is changed. Note that the Set button can be pressed again if the measured position was set incorrectly. When the low limit position has been set, click Next to continue.

**Step 5:**


Set the high limit for the measured position by following the instructions displayed (see below). For indication purposes, the raw position value will be displayed as the actuator position is changed. Note that the Set button can be pressed again if the measured position was set incorrectly. When the high limit position has been set, click Finished to continue.

**Step 6:**

When all calibrations have been performed, send the configuration to the DBW-4 by pressing the F5 key.

## Diagnostic/Fault Condition Monitoring

To view the Diagnostic/Fault Information, select the Monitor Faults option under the File menu. All red indicators indicate an error condition, green indicators indicate OK. Note that if any error conditions are present the particular PID Controller will be shutdown. If any drive by wire type PID Controllers are shutdown then all other drive by wire type PID Controllers will also be shutdown.



## Firmware Upgrades

The Send Firmware option in the File menu can be used to upgrade the firmware of the DBW-4 unit. The DBW-4 unit must be powered and connected to the CAN cable to perform the upgrade.

## Appendices

---

### Appendix A: General Specifications

---

#### ***Physical and Environmental***

Case Size	99 x 105mm x 40mm
Weight	320g
Temperature Range	-10 to 70°C

#### ***Power Supply***

Operating Voltage	9 – 22V DC
Operating Current	150mA (excluding sensor currents and outputs)
Protection	Battery transient protection Reverse battery protection via <b>external</b> fuse

#### ***CAN Communications***

CAN bus speed	1Mbit/s
No CAN terminating resistor onboard	

## **Appendix B: Input Characteristics**

---

### **Analog Voltage Inputs**

Range	0 to 5V
Resolution	4.89mV (10bit conversion)
Input Resistance	100Kohms to 0V
Filtering	Oversampled for anti-aliasing
Update rate on CAN	200Hz (CAN address 0x0F0 or 0x0F8) 50Hz (CAN address 0x0F4 or 0x0FC)

### **Internal Temperature Sensor -**

Resolution            1°C

Accuracy

- DBW-4 case temperature 25°C, +/- 2°C
- DBW-4 case temperature -10 to 70°C, +/- 4°C

## **Appendix C: Output Characteristics**

---

### **Outputs**

Current per output when using the given number of outputs:

- 2 Outputs (1 PID)      2.3A
- 4 Outputs (2 PIDs)    1.6A
- 8 Outputs (4 PIDs)    1.1A

Frequency range for PID PWM outputs 500Hz to approx. 10kHz



## Appendix D: CAN Wiring – Multiple Device


The CAN bus should consist of a twisted pair trunk with 100R (0.25Watt) terminating resistors at each end of the trunk.

The preferred cable for the trunk is 100R Data Cable but twisted 22# Tefzel is usually OK.

The maximum length of the bus is 16m (50ft) including the **MoTeC** CAN Cable (PC to CAN Bus Communications Cable)

CAN Devices (such as **MoTeC** ADL, BR2 etc) may be connected to the trunk with up to 500mm (20in) of twisted wire.


The connector for the CAN Communications Cable may also be connected to the trunk with up to 500mm (20in) of twisted wire and should be within 500mm of one end of the trunk. If desired two CAN Cable connectors may be used so that the **MoTeC** CAN Cable may be connected to either side of the vehicle. Both connectors must be within 500mm of each end of the trunk.



### Short CAN Bus

If the CAN Bus is less than 2m (7ft) long then a single termination resistor may be used. The resistor should be placed at the opposite end of the CAN Bus to the CAN Cable connector.

## Appendix E: DBW-4 to M800 Wiring



### DBW-4 Power and Ground Wiring

Bat +	Bat -
28, 29, 30, 37, 38, 39	13, 14, 15, 19, 20, 21, 22

Additional Power and Ground pins are provided to simplify and to meet the current requirements of any devices connected to the PWM outputs.

As a general principle, if no outputs are being used, then wiring one power and one ground pin is sufficient. If the DBW-4 outputs are used, then all power and ground pins should be wired up.

Wire to suit connector : 22# Tefzel, Mil Spec : M22759/16-22

## Appendix F: DBW-4 Pin List by Pin Number

The DBW-4 uses a 66 pin autosport connector with the following pin-out:

Pin	Function DBW-4	DBW Use	Pin	Function DBW-4	DBW Use
1			34	PID4 PWM 2	DBW 4: PMW2
2	PID4 PWM 1	DBW 4: PMW 1	35	CJC1	
3	PID3 PWM 2	DBW 3: PMW 2	36	8V	
4			37	BATTERY+	
5			38	BATTERY+	
6			39	BATTERY+	
7	PID3 PWM 1	DBW 3: PMW 1	40	RS232 TRANSMIT	
8			41	DIGITAL IN 5	
9			42	DIGITAL IN 6	
10			43		
11			44		
12	RS232 GND		45	8V	
13	BATTERY-		46	5V	DBW 3/4: TP/TP2 +5V
14	BATTERY-		47	CAN0-LO	
15	BATTERY-		48	CAN1-LO*	
16	PID2 PWM 2	DBW 2: PMW 2	49	PID2 PWM 1	DBW 2: PMW1
17	CJC2		50		
18	0V	DBW 3/4: TP/TP2 0V	51		
19	BATTERY-		52		
20	BATTERY-		53	5V	DBW 1/2: TP/TP2 +5V
21	BATTERY-		54	CAN0-HI	
22	BATTERY-		55	CAN1-HI	
23	DIGITAL IN 1		56	PID1 PWM 2	DBW 1: PMW2
24	DIGITAL IN 2		57		
25			58	PID1 MV 1	DBW 1: TP
26			59	PID1 MV 2	DBW 1: TP2
27	0V	DBW 1/2: TP/TP2 0V	60	PID2 MV 1	DBW 2: TP
28	BATTERY+		61	PID1 PWM 1	DBW 1: PMW1
29	BATTERY+		62	PID2 MV 2	DBW 2: TP2
30	BATTERY+		63	PID3 MV 1	DBW 3: TP
31	RS232 RECEIVE		64	PID3 MV 2	DBW 3: TP2
32	DIGITAL IN 3		65	PID4 MV 1	DBW 4: TP
33	DIGITAL IN 4		66	PID4 MV 2	DBW 4: TP2

## **Appendix G: DBW-4 Connector**

---

### **Mating Connector**

Deutsch : AS6-18-35SN

### **Wire**

Wire to suit connector : 22# Tefzel, Mil Spec : M22759/16-22

### **Crimp Tool**

Crimp Tool : M22520/2-01

Positioner for Crimp Tool : M22520/2-07

- Note that the Crimp Contacts are type 22D (this is needed to set the crimp tool correctly)

### **Wire Stripping Tool**

The following tool is recommended

Ideal Industries 45-2133 stripping tool with LB1195 wire stop.

### **Heatshrink Boots**

Straight : Racychem 202K153, Hellermann 156-42-G

Right Angle : Racychem 222K153, Hellermann : 1156-4-G

## Notes

---